
How To Set Up IDMSS Lite IP/DOMAIN For IPhone

Winic Tech www.winictech.com




MAKE SURE YOU ARE CONNECTED TO WIFI, 3G OR 4G (MAKE SURE YOU HAVE INTERNET CONNECTION)

Settings Wi-Fi			
Wi-Fi			
WinicDemo2.4			
CHOOSE A NETWORK			
HP-Print-0A-LaserJ	∻ (i)		
optimumwifi	२ (i)		
Winic 2.4	₽ 奈 ()		
Winic-5g	₽ 중 (j)		
WinicDemo5.0	₽ 奈 (j		
Other			
Ask to Join Networks	\bigcirc		





ONCE DOWNLOADED, OPEN THE APPLICATION





THEN CLICK ON Device Manager





$\langle \rangle$	Unnamed	Ħ
Scan QR Code	e	
Register Mode	9:	P2P
Name:		
SN:		
Username:		admin
Password:		••••
Live Preview:		Extra >
Playback:		Extra >
Sta	art Live Preview	1

CLICK ON REGISTER MODE TO CHOOSE THE TYPE YOU ARE TRYING TO CONFIGURE

FOR THIS EXAMPLE WE WILL USE IP/DOMAIN AS IF YOUR PORTS WERE ALREADY OPEN

Register Mode	
P2P	
Quick DDNS	
Dahua DDNS	
IP/Domain V	
•	
	SELECT THIS OPTION IF YOUR PORTS WERE OPEN
	>

 (\mathbf{H})

1. NAME YOUR DEVICE (ANYTHING)

3. LEAVE AS IS UNLESS YOU CHANGED YOUR DEVICES USERNAME AND PASSWORD

Scan QR Code		
Register Mode:	IP/Domain >	
Name:	winic	
Address:	00.00.000.000	
Port:	37777	
Username:	admin	
Password:	••••	
Live Preview:	Extra >	
Playback:	Extra >	
Start Live Preview		

Unnamed

 \bigcirc

2. YOUR EXTERNAL IP ADDRESS GOES HERE YOU CAN FIND IT AT http://www.yougetsignal.co m/tools/open-ports/

$\langle \cdot \rangle$	Unnamed	
Scan QR Code		
Register Mode	:	IP/Domain >
Name:		winic
Address:	00	0.00.000.000
Port:		37777
Username:		admin
Password:		••••
Live Preview:		Extra >
Playback:		Extra >
Sta	art Live Previ	ew

LEAVE AS IS

CLICK ON THIS ONCE SET UP IS COMPLETE

