Step2 Display bracket Installation

- 1 To ensure optimal installation, this kit includes various screws of differe diameters and lengths.
- 2 Place your TV screen down on a soft,flat surface,and locate the threaded mounting points that are located on the back of the display.
- 3 Determine which screwis (A. B. C. D. E. F. G. H) of the correct length by carefully inserting a straw, or toothpick, and mark how deep the mounting point is.
- 4 If your display has a curved back or a recessed thread mounting point, a spacer must be used, Then you should choose screw to match
- 5 Place the spacer(k) between the mounting bracket and display.
- 6 According to the size of display's hole, choose the corresponding screw and hole on the rectangle washer, then thread them in line.



Step3 Final Installation & adjustment

Hook the TV Rails over the top of the wall plate. The TV Rail could be tilted up and down by 15 degree. And tighten the contral screws by driver to adjust the tilting hardness.

Lock the bracket by the safe lock screws





TENDING INSTRUCTION

Please check whether screws are fixed well each two minths If you have any other doubles regarding the products or the installation, please consult to the special franchiser

Full Motion LED, LCD TV Wall Mount

INSTALLATION MANUAL

PB4085





PLASMA MOUNT INSTALLATION AND OPERATION INSTRUCTION

Warning Statements



1	Prior to the installation of this product, the installation instructions should be read and completely understood. The installation instructions must be read to prevent personal injury and property damage. Keep these installation instructions in an easily accessible location for future reference.
1	Recommended mounting surfaces: wooden studs and solid-flat concrete.If the mount is to be installed on any surface other than wooden studs, use suitable hardware(which is commercially available).
1	Do not install on a structure that is prone to vibration, movement or chance of impact. Failure to do so could result in damage to the display and/or damage to the mounting surface.
1	Do not install near heater, fireplace, direct sunlight, air conditioning or any other source of direct heat energy. Failure to do so may result in damage to the display and could increase the risk of fire.
1	The wall structure must be capable of supporting at least the maximum weight indicated. If not, the wall must be reinforced. Proper installation procedure by a qualified service technician, as outlined in the installation instructions, must be adhered to. Failure to do so could result in serious personal injury
1	A secure structure must support the weight or load of the display. When mounting to a wall that contains wooden studs, dead center of the wooden stud must be confirmed prior to installation.

 \wedge

At least two qualified people should perform the installation procedure. Injury and/or damage can result from dropping or mishandling the display.

Hardware kit:

A	(×4) M4×16 screw	Manage	н	(×4) M8×35 screw	
В	(×4) M4×35 screw		I	(×4) concrete anchor	Contraction of the second
С	(×4) M5×16screw		J	(×4) Bolt	
D	(×4) M5×35 screw		К	(×4) M6 Washer	0
E	(×4) M6×16 screw		L	(×4) M8 Washer	\odot
F	(×4) M6×35 screw	9	М	(×4) M8 Spacer	
G	(×4) M8×16 screw	~~ (3)	Ν		

Tools Required:

\checkmark	Phillips Head Screw driver		
\checkmark	Stud finder for drywall installation		
\checkmark	Socket and Wrench		
\checkmark	Electric drill for concrete/brick installation		

Step1: Wall plate installation

Wood Stud Installation

NOTE: For secure wood stud mounting, the wall plate must be mounted to two studs at least 16" apart.

- 1 Use a high-quality electronic stud finder, (commercially available) to locate two adjacent studs, and mark their locations with a pencil.
- 2 With the help of an assistant and using the bubble level to ensure the wall plate is level, position the wall plate against the
- 3 Mark the right (upper and lower) and the left (upper and lower) positions of the small horizontal slots that are in alignment with the studs.
- 4 You should mark four positions total.
- 5 Next, Pre-drill holes fit for the wall screws in the wall stud at each marked location.
- 6 please position the wall plate against the wall and line up the mounting slots with drilled holes
- 7 For each location, insert a lag bolt and washer into the wall
- 8 Tighten bolt with an open ended socket wrench by turning clockwise until tight.
- CAUTION:Do not over-tighten bolts-doing so many cause unnecessary damage to the wall. Avoid excessive torque.

CAUTION: Do not release the wall plate until it is properly mounted and secured to the wall.

Concrete/Brick Installation

NOTE: The concrete anchors must be used for concrete installation.

- 1 Begin by placing the wall plate into position against the wall, using the bubble level to keep it level.
- 2 Mark off six holes to be used for securing the mount and place the wall plate aside.
- 3 Next,drill holes using an electric drill.
- 4 Insert a concrete anchor into to rach hole.
- 5 If necessary, a hammer can be used to liahtly tap each anchor into place , so that they are flush with the wall.
- 6 Once all of the anchors are in place ,move the wall plate back into position
- 7 Attach the bolt into the washer that is placed in the wall.
- 8 Do not tighten until all screws are in plate.

